



www.clayscapespottery.com

Mixing Instructions -Dipping and Pouring

Start by adding 8 – 10 ounces of water per dry pound of glaze. This will make the glaze to a thicker consistency. If you are mixing Wheat or Desert Sand start with 5 ounces of water per dry pound.

Let the glaze sit overnight so the particles can hydrate.

The next day add water and stir until the glaze becomes the proper consistency. We recommend adding 2 - 4 ounces of water per dry pound of glaze at a time. Then mix and test the consistency before adding more water.

These are intended for dipping/pouring but with modifications you can certainly spray/brush them. If you have any questions, please contact us.

It is important to TEST before you use in production.

If you find the glaze hard panning, then you have added too much water.

Mixing Instructions -Jars for Brushing

These jars of glaze contain 1 pound of dry powdered glaze. The brushing media has already been added so all you need to do is add water - shake and mix. We recommend shaking the glaze in the jar vigorously and then using a power drill with a mixing attachment for a couple of minutes. Some glazes will need to be sieved as well. We still recommend letting the glaze sit overnight and then re-mixing again the next day. Like most brushing glazes be sure to get good coverage for best results. (2-3 coats)

Each of the dry brushing glazes will require you to add 10 – 20 ounces of water depending on the consistency you are looking for. We always recommend starting thick and adding water. It's always easier to add water than to take it away.

Suggested Hydrometer Readings

Glaze	11" Hydrometer Reading	6" Hydrometer Reading	Application
Cream	1.55	52	1 – 2 Dips
Coastal Blue	1.43	43	2 Dip Shake off rim after 1 st dip. Wipe rim after 2 nd dip.
Albany Gold	1.45	45	1 Dip
Garden Green	1.43	44	2 Dips Shake off rim after 1 st dip. Wipe rim after 2 nd dip.
Aqua	1.55	52	1 Dip
Starry Night	1.55	52	2 Dips
Spruce Blue	1.65	57	1 Dip will make it matte. 2 Dips will make it gloss up.
Flame	1.45	45	1 Dip MUST be fired to cone 6
Brick	1.45	45	1 – 2 Dips MUST be fired to cone 6
Redwood	1.45	45	1 Dip Must be fired to cone 6
Royal Purple	1.45	45	1 Dip
Turquoise Rain	1.6	54	1 – 2 Dips
Royal Blue	1.5	47	1 – 2 Dips
Tim's Dark Celadon	1.55	52	1 Dip
Arctic Blue	1.43	43	2 Dips Shake off rim after 1 st dip. Wipe rim after 2 nd dip
Satin Black	1.45	45	1 Dip
Copper Patina	1.45	45	1 Dip
Amber Celadon	1.55	52	1 Dip
Fog Gray	1.5	47	1 Dip
Crystal Clear	1.4	42	1 Dip
Shadow Blue	1.5	47	1 Dip
Wheat	1.65	57	1 – 2 Dips
Frosted Mint	1.65	57	1 – 2 Dips
Pacific Blue	1.55	52	1 Dip
Smokey Purple	1.5	47	1 Dip
Pitch Black	1.5	47	2 Dips
Clinton Pottery Red	1.45	45	2 Dips
Lake Effect White	1.45	45	1 Dip
Desert Sand	1.65	57	1 Dip
Flatbush	1.5	47	1 Dip
Crown Heights	1.5	47	1 Dip
Greenpoint	1.5	47	1 Dip
Coney Island	1.5	47	1 Dip
Sunset Park	1.5	47	1 Dip
Brighton Beach	1.5	47	1 Dip

Park Slop	1.5	47	1 Dip
Red Hook	1.5	47	1 Dip
Bushwick	1.5	47	1 Dip
Butter	1.65	57	1 Dip
Bright White	1.6	54	1 Dip
Aurora	1.5	47	2 Dips Consecutively
Nebula	1.62	55	1 – 2 Dips
Jess's Chun Blue	1.6	54	2 Dips
Spearmint	1.65	54	1 – 2 Dips
Cobblestone	1.5	47	1 – 2 Dips
Lake Blue	1.5	47	1 – 2 Dips
Oribe	1.6	54	1 – 2 Dips
Cranberry	1.45	45	1 – 2 Dips
Black Copper	1.5	47	1 Dip
Nutmeg	1.5	47	1 Dip
Ultraviolet	1.55	52	2 Dips
Charcoal	1.55	52	1 Dip